



## CORD SET INSTALLATION

1. Knock out "double D" hole and pass line cord thru.
2. Using the wire nuts supplied connect the line cord leads to the primary leads of the transformer.  
White to white and black to black.
3. Connect the cord green ground lead to the housing green ground lead.
4. Squeeze the Heyco strain relief around the cord close to the "double D" hole and push in using pliers.