

INSTALLATION WITH TOP CONNECTOR BOX

1. REMOVE COVER PLATE AND SLIDE MOUNTING BOX FROM FIXTURE. THREAD BOX ONTO 3/4" CONDUIT, HOOK (SHOWN) OR LOOP. SLIDE FIXTURE ONTO BOX.
2. CONNECT WIRING.
3. FOLD LEADS AND GROUND WIRES INTO MOUNTING BOX. REPLACE COVER PLATE, TIGHTEN COVER PLATE SCREWS. CHECK ALL SCREWS IN MOUNTING BOX FOR TIGHTNESS. ORIENT FIXTURE AS DESIRED. TIGHTEN SAFETY SET SCREW IN TOP OF MOUNTING BOX BESIDE CONDUIT ENTRY TO PREVENT ACCIDENTAL ROTATION. TO PREVENT CANTILEVERING AND TORQUE, CHAIN OR CABLE MUST BE USED ON BOTH ENDS.

