


AUTOMATIC MODE OPERATION:

1. WHEN SENSOR ACTIVATES LOAD TURNS ON.
2. LOADS TURN OFF WHEN SENSOR TIMES OUT.

RECOMMENDED WIRE:
18-3 AWG STRANDED WIRE SHIELDED OR NON/SHEILED



NOTES

1. SP20-MV SWITCHPACK SHOWN, 120/277VAC 20AMP RATING.

TO ADDITIONAL SENSORS
MAXIMUM OF 5 SENSORS PER SWITCHPACK.

- NOTES:
1. SENSOR TYPE INCLUDE OAWC-P-120W, OAWC-P-009L-H
 2. SP20-MV SWITCHPACK SHOWN. REFER TO CUT SHEETS AND/OR INSTALLATION INSTRUCTIONS FOR OTHER GREENGATE SWITCHPACK WIRING.



PRODUCT WALL/CORNER SENSOR WIRING DIAGRAM

TITLE SINGLE SENSOR AUTOMANUAL ON/OFF CONTROL

Tel: 1-800-553-3879
 Fax: 1-800-954-7016
 Addr: 203 Cooper Circle
 Peachtree City, GA 30269, USA
 ControlsSales@cooperindustries.com
 www.coopercontrol.com

DRAWN BY CHKBY CHECKED BY APPBY

DATE 05-29-2013

DWG NO. W3-1S1-1-0000-000

REV. A