

# SURE-LITES

## Installation Instructions for the Sure-Lites EZ Key

Installation of the external battery disconnect for use with emergency products

### IMPORTANT SAFEGUARDS

**WHEN USING ELECTRICAL EQUIPMENT, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE OBSERVED INCLUDING THE FOLLOWING:**

#### 1. READ AND FOLLOW ALL SAFETY INSTRUCTIONS

2. Do not use in hazardous locations, or near gas or electric heaters.
3. Do not let power supply cords touch hot surfaces.
4. Use caution when servicing batteries. Battery acid can cause burns to skin and eyes. If acid is spilled on skin or in eyes, flush acid with fresh water and contact a physician immediately.
5. Do not use this equipment for other than the intended use.
6. Installation is to be performed only by qualified personnel.
7. Install in accordance with National Electric Code and local regulatory agency requirements.
8. The use of accessory equipment not recommended by the manufacturer may cause an unsafe condition.
9. Equipment should be mounted in locations and at heights where it will not readily be subjected to tampering by unauthorized personnel.
10. Caution: Halogen cycle lamps may be used in this equipment. To avoid shattering: Do not operate lamp in excess of rated voltage, protect lamp against abrasion and scratches and against liquids when lamp is operating, dispose of lamp with care.
11. Halogen cycle lamps operate at high temperatures. Do not store or place flammable materials near lamp.

#### 12. SAVE THESE INSTRUCTIONS

#### **WARNING**

Risk of Fire/Electric Shock.

If not qualified, consult an electrician.

#### **WARNING**

Risk of Electric Shock.

Disconnect power at fuse or circuit breaker before installing or servicing.

### INSTALLATION:

- Step 1.** Install product as described in the main instruction sheet.
- Step 2.** After connecting the battery, test the unit by turning on the AC power.
- Step 3.** Disconnect the AC power. The unit should go into emergency mode.
- Step 4.** Insert the Sure-Lites EZ Key battery disconnect in the hole labeled "Battery Disconnect". The battery is now disconnected from the circuitry, and will remain so until the key is removed.
- Step 5.** When the unit is ready to enter regular service, remove the Sure-Lites EZ Key and discard it, then apply AC power. The unit will now operate normally.

