

PLAYBOOK RETROFIT INSTALLATIONS

CONTENTS

00 BEFORE YOU BEGIN

PG 5 SAFETY STATEMENT

01 SYSTEM SOLUTIONS

PG 6 PRODUCT LINE

02 GET STARTED

PG 8 SITE EVALUATION PG 9 SITE PRE-ASSESSMENT CHECKLIST

03 GAME PLAN SUMMARY

PG 10 DESIGN & DELIVER PG 11 INSTALL & TEST

04 EPHESUS RETROFIT SYSTEM

PG 12 WE HAVE YOUR SOLUTION PG 13 CONTROLS OVERVIEW

05 INTEGRAL RETROFIT

PG 14 EXISTING INTEGRAL RETROFIT PG 15 MOUNTING SOLUTIONS

06 REMOTE RETROFIT

PG 16 EXISTING REMOTE RETROFIT PG 17 MOUNTING SOLUTIONS PG 18 DISTRIBUTION BOX BYPASS DIAGRAM PG 19 WIRING OVERVIEW

07 LUMINAIRE INSTALLATION

PG 20 MOUNT & PRE-AIM PG 21 PLUG & PLAY





We are a team of insight-driven global innovators with an uncompromising commitment to transforming the places we live, work and play. We build and deliver high performance sports lighting solutions. We strive to provide exceptional customer service from idea to implementation.

Ephesus Sports Lighting 125 East Jefferson Street Syracuse, NY 13202 1-800-573-3600

EPHESUSLIGHTING.COM



SAFETY STATEMENT

Before You Begin

This playbook is only a summary. It is not intended to be a detailed set of installation instructions. For detailed installation instructions, please refer to the relevant product installation manual(s). If you have any questions regarding the product or installation, contact Cooper Lighting Customer Service at 1-800-573-3600.

Follow all safety items outlined here as well as any local safety procedures.

- applicable local codes and ordinances.
- 2. Verify the capacity and integrity of existing power distribution system and correct branch circuit voltage before beginning installation.
- before installation. See fixture specification sheet for weight and wind loading data.
- 4. In harsh settings where the system is subjected to factors such as extreme temperatures, high system.
- 6. Use Personal Protective Equipment including hardhats, safety glasses, reflective vests, electrical maintenance of luminaire.
- 7. Verify compliance with local standards to prevent access to the area below where installation activities are occurring to prevent injury from accidental drops of fixtures, tools or hardware.

Disclaimer of Liability:

Cooper Lighting Solutions and Ephesus Sports Lighting assumes no liability for damages or losses of any kind that may arise from the improper, careless, or negligent installation, handling or use of these products.

Cooper Lighting Solutions. All Rights Reserved. Specifications and dimensions subject to change without notice.





1. All electrical work must conform to National Electrical Code (NFPA 70), IEEE Emerald book, and all

3. Verify the structural capacity and safety of all facility/venue/pole supports and mounting apparatus

corrosion, hurricanes, or lightning, always follow local codes and additional protocols to ensure the cabling and other system components can withstand the environmental stress for the life of the

5. DO NOT make or alter any open holes in the luminaire. Do not modify the luminaire, internal wiring, or fixture mounting features. Opening or modifying the luminaire or bracket will void the warranty.

safety gloves, fall protection equipment, and safety toe boots during installation, operation, and

LOWEST TOTAL COST OF OWNERSHIP

Ephesus Luminaires combine interchangeable modular power, controls, and easy-to-install mounting options. An Ephesus Sports Lighting system delivers the optimum solution for every indoor and outdoor sports venue with industry-leading reliability.



PRODUCT LINE





LUMINAIRE TYPE





LUMAVISION White LED

PRISM RGBA

RGBA Color LED







TRANSFORMING THE GAME

Ephesus has developed the first true LED sports-lighting system, giving you more than just a fixture to power your performance. Today's venues demand lights that have proven performance at the highest levels. With crisp lighting and dynamic scenes for the fans at the game, Ephesus provides the most exciting game-day experience for your audience—and the best light for the athletes, so they can perform at their peak

0000 0000 0000 0000





SITE EVALUATION FACTORS

LUMINAIRE MOUNTING IS DIFFERENT

Gather existing system configuration details to provide appropriate accessories for a proper installation. (crossarm clearance and mounting)







POLE POSITIONING VARIES

Gather accurate site measurements for photometric design creation. (pole height, pole set back, pole spacing, crossarm height, etc.)









INFRASTRUCTURE IS OLD

Validate existing mechanical/electrical system can support a retrofit LED system. (provided by 3rd party)







SITE PRE-ASSESSMENT CHECKLIST















GET STARTED







1 DESIGN & DELIVER

- Lighting Design Proposal
 - Quotation/Bill of Materials (BoM)
 - Photometric Drawing Design Plan •
 - Product Specification Sheets
 - Product Installation Manuals
 - Installation Drawings •
 - Foundation Design
 - Project Management Services •
 - Warranty & Order Confirmation Packet •



Accept delivery

2 INSTALL & TEST

- Disconnect system power •
- Remove the existing lighting system and infrastructure as needed
- If applicable, install new crossarms and mounting accessories ٠
- Mount and pre-aim Ephesus luminaires
- Finish luminaire and lighting system electrical connections in accordance • with NEC and IEEE Emerald Standards
- Commission system controls and check light levels on site







WE HAVE YOUR SOLUTION

The Ephesus Retrofit System converts your existing remote or integral system to an integral LED sports lighting system with industry leading reliability and performance. In a existing remote power configuration the ballasts in the power box are typically located at the bottom of the pole. In an Ephesus Retrofit System the Ballasts in the power box are bypassed in order to bring AC power to the top of the pole. The diagram below illustrates a successful Ephesus Retrofit System.



TAKE CONTROL OF YOUR SPORTS LIGHTING



CONTROLS OVERVIEW

EXAMPLE SYSTEM TOPOLOGY (WIRELESS AIRMESH CONTROLS)

Example system topology showing the LUMASPORT 8 System in a Wireless AirMesh Control Installation. Note: Laptop or mobile device not included. A cellular network connection requires a cellular carrier network plan.





INTERNET CONNECTED DEVICES ALLOW SECURE ACCESS TO LIGHTING SYSTEM CONTROLS WEB PAGE

OR WEB APPLICATION

EXAMPLE SYSTEM TOPOLOGY (CONTACTOR CONTROLS)

Example system topology showing the LUMA**SPORT 8** System in a Wired Contactor Controls Installation, Note: Laptop or mobile device not included. A cellular network connection requires a cellular carrier network plan.



INTERNET CONNECTED DEVICES ALLOW SECURE ACCESS TO LIGHTING SYSTEM CONTROLS WEB PAGE

page 12



EPHESUS LUMINAIRES

EXISTING INTEGRAL RETROFIT



EXISTING INTEGRAL SYSTEM

Ephesus luminaires are designed to mount directly to the infrastructure that exists. In the cases where this is not possible, Ephesus has mounting accessories and a pre-wired crossarm solutions to accommodate the wide variety of existing structures. This includes solutions for platforms, cages, crossarms, as well as fastening hardware used to mount luminaires.

EPHESUS RETROFIT SYSTEM

EXISTING 1:1 MOUNTING

- Keep crossarm
- Keep wiring
- Mount luminaires to existing mounting locations.

EXTENSION PLATE

2

• If needed, use the Extension Plate to create clearance

MOUNTING SOLUTIONS

The existing luminaires are removed, and the remaining infrastructure is prepared for the retrofit installation. Your Ephesus luminaires arrive at the venue, ready to be installed.





Extends and creates clearance at an existing mounting location by fastening and clamping to crossarms & platforms







PLATFORM & CAGE VARIATIONS

EXISTING 1:1 MOUNTING



EXTENSION PLATE



EXISTING REMOTE RETROFIT



EXISTING REMOTE SYSTEM

Ephesus luminaires are designed to mount (1 directly to the infrastructure that exists. In the cases where this is not possible, Ephesus has mounting accessories and a pre-wired crossarm solutions to accommodate the wide variety of existing structures. This includes solutions for platforms, cages, crossarms, as well as fastening hardware used to mount luminaires.

EPHESUS RETROFIT SYSTEM

NEW PRE-WIRED CROSSARM

- Remove existing crossarm
- Remove existing wiring
- Mount luminaires to Pre-Wired crossarm
- Attach Pre-Wired crossarm to Pole
- Bypass existing Ballast

DIVING BOARD

- Keep existing crossarm
- Keep existing wiring
- Mount luminaires with Diving Board
- Bypass existing Ballast

MOUNTING SOLUTIONS

The existing luminaires and crossarms are removed, and the remaining infrastructure is prepared for the retrofit installation. Your Ephesus luminaires and pre-wired





Creates a new mounting platform location by clamping to industry standard 2in x 4in rectangular crossarms





PRE-WIRED CROSSARM

LIFT TO LOCATION







DISTRIBUTION BOX BYPASS DIAGRAM

OUTGOING AC POWER BALLAST FUSE BLOCK **GROUND WIRE** INCOMING AC POWER

EXISTING REMOTE SYSTEM

Typical existing remote systems utilizing an electrical components enclosure that houses the HID ballasts. Each HID ballast powers one light head and is individually fused and grounded for electrical protection of the system. When converting to the Ephesus integral system the ballasts are electrically bypassed in order to bring power to the Ephesus luminaires at the top of the pole.

EPHESUS RETROFIT SYSTEM

- 1. Disconnect the old ballast wiring
- 2. Inspect current existing system to ensure it's properly rated for the incoming AC power.
- 3. Connect the existing fixture circuit wiring directly into the fuse blocks, bypassing the ballasts
- 4. This provides line voltage up to the fixture location





- 1. Use the diving boards at fixture locations
- 2. Use cap to plug hole on underside of crossarm
- a. Drill hole through center of plug for new fixture wires

3. Make electrical connections

- a. Feed new fixture wires through center of cap
- b. Splice new fixture wires to existing fixture feeds
- c. Fixture must have ground wire (EGC) back to power source
- d. Push splices/wire nuts up into crossarm
- e. Set plug into crossarm, making sure not to pinch wires.



IN THE BALLAST BOX



- 1. Reconfigure wiring to feed branch circuits directly up to fixtures.
 - a. Wire directly from fuse block to fixtures (bypass ballasts)
 - b. This sends line voltage up to fixtures
 - c. Cut/disconnect wiring from fuse blocks to ballasts and from ballasts to fixtures, leaving as much slack in fixture feeds as possible
 - d. Splice/reconnect wires from fuse blocks to fixture feeds
 - e. Inspect fuse terminals to ensure there is no corrosion







STEP 1: MOUNT DRIVER BOX WITH ORIENTATION

· Mount driver boxes to crossarm, laterally Pre-Aim driver boxes according to the provided Photometric Design Plan and connect power according to the provided luminaire Installation Manual(s)



STEP 2: SET "QUICK MOUNT YOKE" FOR TILT

• Vertically Pre-Aim Mounting Arms according to provided Photometric Design Plan, place the Light Heads into the Mounting Arms and tighten Tilt Lock Screws.



STEP 3: CONNECT POWER



• Attach all Kellem Grip Drop Cables to the Strain Relief Clips located above each Distribution Box at Pole Base.



page 20



PLUG & PLAY



• Wire the Pre-wired crossarm to the Driver Box and connect the Light Head to the Driver Box



Pre-Wired crossarm and connect electrical with the Multi-Pin Quick Connectors in the



GET STARTED



EPHESUSLIGHTING.COM





J)