
## ONW - MANUAL MODE

- 1. SWITCH IS REQUIRED TO TURN LOAD ON.
- 2. LOAD TURNS OFF WHEN SENSOR TIMES OUT OR WITH SWITCH.
- IF DAYLIGHT SENSOR IS ENABLED AND LIGHT LEVEL IS ABOVE SETPOINT, LOAD WILL NOT TURN ON.

## ONW - AUTOMATIC MODE

- 1. WHEN SENSOR ACTIVATES LOAD TURNS ON.
- 2. SWITCH CAN BE USED TO TURN LOAD ON OR OFF.
- 3. IF DAYLIGHT SENSOR IS ENABLED AND LIGHT LEVEL IS ABOVE SETPOINT, LOAD WILL NOT TURN ON.

SENSOR TYPE INCLUDES: ONW-P-1001-RR7



## PROJECT NAME PROJECT SUBNAME

TITLE: Device



THE INFORMATION ON THIS DRAWING IS THE PROPERTY OF EATON CORPORATION. IT IS DISCLOSED IN CONFIDENCE AND IS NOT TO BE REPRODUCES, USED, OR DISCLOSED EXCEPT FOR THE PURPOSE FOR WHICH FURNISHES.

DRAWN: X.X.	DATE: 13/03/14	PROJ:				
CH'KD: X.X.	SCALE: NTS		-	-	-	_
		DWG #:	-	-	-	-
APPR: X.X.	SHEET: 1/1		-	=	-	_
		123456789012	-	_	-	-
	SIZE: A		DATE	REV	DESCRIPTION	BY
			REVISION TABLE			